INSPECTION 1

ALL DERIVATIVES to 05 MY

Invoice No
Registration Date
Registration No
Odometer Reading
VIN

Adjust/Lubricate/Renew - Labour cost included in scheduled times except items marked *.

Check - After checking procedure, cleaning, repairing or replacing is subject to extra labour and material cost.

VE	HICLE INTERIOR	17
1.	Reset the Service Interval Indicator.	
2.	Check operation of parking brake.	
3.	Check operation of all lamps, horns and warning indicators.	
4.	Check operation of front/rear wipers and washers and condition of wiper blades.	
5.	Check condition and security of seats and seat belts.	
6.	Replace airbag SRS and seat belt pre-tensioners*. (every 15 years)	

VEHICLE EXTERIOR	٧X
7. Check tyres pressures, and adjust if necessary.	
8. Remove road wheels.	
 Check brake pads for wear, calipers for leaks and discs for condition. 	
10. Grease wheel centre surfaces.	
11. Check tyres for damage, condition and tread depth.	
 Refit road wheels to opposite sides of the same axle. (Ref. Bulletin 0032 - Suspension) - NOT vehicles fitted with uni-directional tyres 	4
13. Apply lubricant to top edge of door seals.	

UNDER BONNET	√×
14. Check battery condition.	
15. Check/top up battery electrolyte level where applicable	
16. Replace pollen filter.	
17. Check condition of ancillary drive belt.	
18. Check/top up brake, PAS and screen washer fluid levels.	
19. Replace brake fluid every 3 years*.	
20. Replace radiator top hose and heater feed hose assemblies every 60,000 km (V8 Gulf markets only) *.	
21. Check coolant level, change coolant every 4 years*.	

UNDER VEHICLE	√X
22. Replace engine oil and filter.	
23. Check all powertrain components for fluid leaks.	
24. Check steering components for security and wear.	
25. Check suspension fixings.	



UNDER VEHICLE

26 Check brake fuel I	PAS and suspension pipes and
	urity, leakage, corrosion and possible
chafing.	

1X

27. Renew petrol fuel filter every 150,000 miles.*

ANTI - CORROSION CHECK LIST . 28. Visually check the underbody sealer for damage (pay particular attention to areas of apparent repair). . Using an inspection lamp, check for corrosion/damaged underbody sealer on: . 29. Sills and wheel arches. .

30. Main floor.

- 31. Subframe.
- 32. Areas adjacent to suspension mounting and fuel tank fixings.

NOTE: Small blisters in the PVC underbody sealer are acceptable providing they do not reveal bare metal.

 Inspect an report, exterior paintwork for damage and body panels for corrosion (pay particular attention to areas of apparent repair).

Visually check for evidence of damage and corrosion on all paint finished areas particularly:

- 34. Front edge of bonnet.
- 35. Lower body and door panels.
- 36. Check visible flanges in engine and luggage compartments.37. Check clinched edges and hinge areas of bonnet.
- 38. Remove interior vehicle protection kit.

Please tick one of the following boxes.

39. Remedial work required, list below.

- 53. Remedial work required, list beic
- 40. NO remedial work required.

ROAD TEST	٧X
41. Road test vehicle.	
42. Endorse service record.	
43. Check for any applicable outstanding service actions or recalls.	
44. If fault lamp(s) are illuminated, interrogate that system using T4/IDS and report findings.*	
45. Report any unusual features of the vehicle condition and additional work required.	